



Tong Metal Pty Ltd
ABN 15 336 691 296 • ACN 120 852 824
9 Hamilton St, Northgate QLD 4013
Phone: (07) 3256 9633 • Fax: (07) 3256 8188
Email: cindy@tongmetal.com.au
Web: www.tongmetal.com.au

Tong X-Roof Canvas Care Instructions

Background

The canvas used in your Tong X-Roof Camper is by DFAB Australia in Campbellfield, Victoria.

defab® have developed a unique proofing system branded DDP that ensures maximum protection and opacity providing the end user with the ultimate canvas.

All defab® canvas is manufactured to withstand the extremes of Australian weather conditions.

The DDP process and are the most durable, opaque and most waterproof canvas available on the market.

**Details of guarantee available from defab® <https://defab.com.au/>*

When your canvas requires rejuvenation, use reproof® by defab® which is an environmentally friendly waterproof compound. Give your weathered canvas new life with reproof® by defab®.

Canvas care instructions:

- We recommend that you thoroughly wet new canvas before use and let it dry in the sun. Failure to do so may cause leakage during initial exposure to rain.
- Product must be completely dry and clean prior to storage.
- Clean only with cold water and a soft brush
- Do not use soaps or detergents and do not scrub the fabric.
- Do not expose to petrol, oil, or solvents.
- Should mildew appear, remove first by brushing, then by treating with diluted chlorine bleach (typically 1-part liquid bleach to 4 parts water). Rinse well and dry fully.
- Do not use strong bleaches such as “pool chlorine”.
- Occasionally rejuvenation of your canvas is suggested using defab® approved canvas treatments.